

## 1991 BMW 735i

Copyright © 1998 Mitchell Repair Information Company, LLC

Monday, November 20, 2000 01:41PM

**COMPONENT LOCATOR:**

A/C CONTROL UNIT	C-24-27
A/C RELAY	D 28
A/C RANGE SW	A-E 30-31
A/C SWITCH	C 32
ABS CONTROL UNIT	A-B 30
ABS HYDRAULIC UNIT	A-B 23
ALTERNATOR	C 3
ANTI-LOCK AMC	A 66
ANTI-THIEF HORN	C 45
ANTI-THIEF MODULE	B-C 47
AUXILIARY FUSE BOX	C 14-15
BACK-UP LT SW	C 42
BATTERY	A 2
BLOWER MOTOR	E 12
BLOWER RELAY	C 26
CLIMATE MODULE	A 44
CH-ME MODULE	E 52
CLG LTRAS	E 55
COMBINATION SW	C 36
COMPRESSOR CLUTCH	C 36
COMPRESSOR CONTROL UNIT	B 36
COOLANT LEVEL SW	A 46
CLOCK CONTROL MODULE	C 52
CRUISE CONTROL SW	C-D 32
DEFOG GRID	B 86
DIAGNOSTIC CONN	A 44
DOOR/LOCK MOTOR	B 38
DOOR/LOCK MAP READING LT ASSEMBLY	D 55-50
DOOR LOCK MOTORS	E 48-50
DOOR LOCK SW	A 43
DOOR SAT	A 68
DRIVERS SEAT LUMBAR SW	C 43
ELECTRONIC TRANSMISSION CONTROL (ETC) UNIT	C-E 20
FLAME STAGE UNIT	E 25
FLASH/CHARGING PLUG	E 36
FLG LT SW	B 36
FOOTWEAR	C 52
FRONT OIL/WATER PUMP RELAY	D 12
FRONT PUMP DISTRIBUTION	A 38
FOX (FNT PDB)	B-E 10-13
FUEL INJECTOR WINDOW SW	E 47
FUEL PUMP WINDOW SW	E 47
FUEL TANK SENSOR	D 67
GENERAL MODULE	A-E 51
GLASS	D 58
HAZARD FLASHER RELAY	D-E 36
HAZARD SW	C 36
HEADLIGHT RELAY FOG LT MODULE	B 36
HORN SPEED RELAY	C 11
HORN RELAY	E 28
IGN COIL	A 5
IGN SW	A 5
IGNITION SW	D 7
INTERIOR SW	C 37
INFARED LOCKING UNIT	D-E 83
INFARED/ANTI-THIEF LED	E 62
INSTRUMENT CLUSTER	A-E 40-41
JACKER PLUG (M/T)	C 11
K3 UNLOADER RELAY	C 11
K4 UNLOADER RELAY	B 11
LEFT REAR WINDOW SW	D 13
LEFT REAR WINDOW SW	E 55
LIGHT SW	A 36
LT CONTROL MODULE	D-E 39
MAIN FUEL PUMP	C 36
MAIN RELAY	A 6
MEMORY SEAT/MIRROR CONTROL UNIT	D 55-59
MIRROR CONTROL SW	D 54
MIRROR MOTOR	C 64
MOTRONIC CONTROL UNIT (MCU)	B-E 4
NORMAL SPEED RELAY	D 30
ON-LEVEL SENSOR	D 30
ON BOARD COMPUTER (OBC)	D-E 44
P/S F/LD LEVEL SW	A 44
PARKING SENSOR	C 36
PARK VENT RELAY BOX	C 29
PHONE TRANSCIVER	D-E 15
POWER ASSIST STEERING	C 23
POWER PROTECTION RELAY	D 23
PROGRAM SW	D 23
READING LTS	D-E 55
REAR DEFOG RELAY	D 18
REAR DEFROST DISTRIBUTION BOX (REAR PDB)	B-D 17-19
REAR SEAT CONTROL SW/S	A-B 51-52
RELAY MODULE	A-C 48
RIGHT REAR WINDOW SW	D 13
RIGHT REAR WINDOW SW	A 55
SEAT HEATER RELAY	E 80
SEAT HEATER RELAY	B 83
SEAT HEATER/POSITION RELAYS	D 80
SRS DIAGNOSTIC MODULE	A-B 35
STARTER MOTOR	C-D 3
STARTER RELAY (A/T)	D 3
TOP LT SW	C 37
SUNROOF MOTOR	B 64
SUNROOF POSITION SW	A 64
SUNROOF SW	B 64
TEMP DISTRIBUTION	E 26
POTENTIOMETER	E 46
"HOTTLE SW	E 46
TRUNK COMPARTMENT LT	U 66
"TRUNK LOCK MOTOR	E 60
TRUNK LOCK SW	C 45
"TRUNK LT	A 53
TRUNK SW	E 56
UNDERHOOD LT	E 3
WASHER MIRROR LTS	B 66
WASHER FLUID LEVEL SW	A 66
WASHER JET HEATERS	C 35
WASHER MOTOR	C 35
WASHER PUMP RELAY	C 33
WASHER VALVE ASSEMBLY	A 28
WINDOW LIMIT SW	A 53
WINDOW MOTORS	C-E 55
WIPER MOTOR	C 32
WIPER SW	A 28
WIPER/WASHER SW	A 32

